INSTALLATION INSTRUCTIONS

	Failure to follow these instructions can severely shorten the life of this part and may void the part's warranty.
<u> </u>	nstallation Process
	If you are replacing the Original Equipment Coil, you may have to destroy the original attachment devices to
	remove the coil. If this is the case, you will have to supply bolts, nuts and lock washers to install the
	replacement coil
	Recommended: Two (2) each of: #8-36 x 1.25 hex flanged bolt; #8 lock washer and #8-36 flanged nut.

Models covered:

50007 2-50007