

INSTALLATION INSTRUCTIONS

Failure to follow these instructions can severely shorten the life of this part and may void the part's warranty.

Installation Process

- 1) Remove screens within distributor per OE TSB 03-06-04-041A to allow proper ventilation of distributor and eliminate possibility of failure due to internal moisture, corrosion, and subsequent arcing between terminals.

- 2) Ensure distributor cap mounting holes located on plastic body of distributor are free of old dried Loctite originally applied to OEM mounting screws. Residual dried material can cause distributor mounting holes to split when new screws are installed.

Models Covered:

40005	40005HP	
40006	2-40006	40006HP