

## **INSTALLATION INSTRUCTIONS**

Failure to follow these instructions can severely shorten the life of this part and may void the part's warranty.

### **Installation Process**

1. Lock cylinder is shipped ready for installation. Do not rotate the key clockwise until lock cylinder is installed into steering column.

### **Proceso de Instalacion**

1. El interruptor de arranque esta listo para su instalacion. No gire la llave hasta que haya sido instalado en la columna del volante

Models Covered:

ILC174

IS 23-7-29-09