

**INSTALLATION
NOTE**

FOR THE INSTALLATION OF
THIS COIL,
AN EXTERNAL
RESISTOR IS REQUIRED

MODELS AFFECTED 50000

IS 25 DTD 11-18-10

**INSTALLATION
NOTE**

FOR THE INSTALLATION OF
THIS COIL,
AN EXTERNAL
RESISTOR IS REQUIRED

MODELS AFFECTED 50000

IS 25 DTD 11-18-10

**INSTALLATION
NOTE**

FOR THE INSTALLATION OF
THIS COIL,
AN EXTERNAL
RESISTOR IS REQUIRED

MODELS AFFECTED 50000

IS 25 DTD 11-18-10

**INSTALLATION
NOTE**

FOR THE INSTALLATION OF
THIS COIL,
AN EXTERNAL
RESISTOR IS REQUIRED

MODELS AFFECTED 50000

IS 25 DTD 11-18-10

**INSTALLATION
NOTE**

FOR THE INSTALLATION OF
THIS COIL,
AN EXTERNAL
RESISTOR IS REQUIRED

MODELS AFFECTED 50000

IS 25 DTD 11-18-10

**INSTALLATION
NOTE**

FOR THE INSTALLATION OF
THIS COIL,
AN EXTERNAL
RESISTOR IS REQUIRED

MODELS AFFECTED 50000

IS 25 DTD 11-18-10

**INSTALLATION
NOTE**

FOR THE INSTALLATION OF
THIS COIL,
AN EXTERNAL
RESISTOR IS REQUIRED

MODELS AFFECTED 50000

IS 25 DTD 11-18-10

**INSTALLATION
NOTE**

FOR THE INSTALLATION OF
THIS COIL,
AN EXTERNAL
RESISTOR IS REQUIRED

MODELS AFFECTED 50000

IS 25 DTD 11-18-10