

INSTALLATION INSTRUCTIONS

Failure to follow these instructions can severely shorten the life of this part and may void the part's warranty.

Installation Process

- A. Shut off engine
- B. Unplug the connector from the old Module.
- C. Loosen the mounting screws and remove the old module.
- D. **IT IS ABSOLUTELY REQUIRED THAT YOU APPLY THE THERMAL GREASE PROVIDED TO THE METAL SIDE OF THE MODULE!** Failure to do so will shorten the life of the module and void the warranty. Clean the mounting surface of old grease, dirt and any corrosion found.
- E. Install the new module and tighten the two screws evenly and being sure to maintain even contact with the base.
- F. Plug the connector into the new Module.

Models Covered:

7109	
7137	2-7137
7138	

IS6-1-17-08